

VI.3.6A-SETUP FFGUID SETUP MENU

Parametric information is maintained for the FFGS through the Setup Menu and sub-menus. The Setup menu shows the functional types: Grid, Areas (county, urban area), Headwaters, Intensity/Overbank and User Information and Options. A sub-menu for each of the items on the Setup Menu provides an interactive capability to Add, Change, Delete or List parameters associated with the selected type. The Add and Change selections provide the capability to input parameters from a file, if desired. Parameters can be written to a file using the List function and subsequently read in using the Add or Change function for file input.

The main menu appears as:

```

      N A T I O N A L   W E A T H E R   S E R V I C E
      F L A S H   F L O O D   G U I D A N C E   S Y S T E M
PROGRAM FFGUID   - RELEASE nnnn   - mm/dd/ccyy

      Setup Menu

      G - Grid
      A - Areas
      H - Headwaters
      R - Runoff Adjust for Grids
      W - Water Supply
      U - User Controls & Options

      C - Computation Menu (previous menu)

Select (<return>-exit):
```

The purpose and description of each item on the FFG Setup Menu follows.